




150099 LARGE SOFA




150018L LEFT ARM SOFA W/RETURN




150018R RIGHT ARM SOFA W/RETURN




150014 ARMLESS SOFA




150017L LEFT ARM SOFA




150017R RIGHT ARM SOFA




150007L LEFT ARM CHAISE




150007R RIGHT ARM CHAISE




150020 SOFA




150001/ OTTOMAN




150009 ARMLESS LOVESEAT



150002 ARMLESS CHAIR



150011L LEFT ARM LOVESEAT W/RETURN



150011R RIGHT ARM LOVESEAT W/RETURN


ARM PILLOW
18" X 18"

Scale: 1/4" = 1'-0"
*NOTE: L or R is determined by facing the piece.


OVERALL DEPTH 37"
SEAT DEPTH 20"
FRAME HEIGHT 30"
S H 19"

OVERALL WIDTH 40"
ARM HEIGHT 25 1/2"
OVERALL HEIGHT 34"


*NOT TO SCALE




150070 STUDIO SOFA




150051
CONDO SOFA




150050L
LEFT ARM CONDO SOFA




150050R
RIGHT ARM CONDO SOFA




150064L
ARMLESS LOVE WITH LEFT BUMPER




150064R
ARMLESS LOVE WITH RIGHT BUMPER




150061L
LEFT ARM ANGLE SOFA




150061R
RIGHT ARM ANGLE SOFA




150010L
LEFT ARM LOVESEAT




150010R
RIGHT ARM LOVESEAT




150013
LOVESEAT




M150004 CHAIR



150005/ L OR R
CORNER CHAIR



150003L
LEFT ARM CHAIR



150003R
RIGHT ARM CHAIR